

Basic Troubleshooting

Eagle Eye

Software: Most software problems occur when the internal software settings or options are unknowingly changed by the user. When this happens, the software may function differently from what the user expects.

The Computer playback is jumpy and fuzzy

1. **With video on the screen**, press the **ENTER** key to bring up the RACE PROPERTIES box.

Make sure **PROGRESSIVE SCAN** is off (unchecked) and playback is set to 59.94.

- 2.

Tip: This setting may become altered after importing video from another source.

